

BIOS upgrade HPE DL 380 G6

- Download OS Independent BIOS upgrade:

HPE ProLiant DL380 G6 Server

Direct link: **** CRITICAL **** [System ROMPaq Firmware Upgrade for HP ProLiant DL380 G6 \(P62\) Servers \(For USB Key-Media\)](#)

- Get a USB Key (e.g. 4GB) and format it with NTFS
- Execute the downloaded file: SP99323.exe (2.8 MB) and follow the guide, when done
- Insert the USB Key into the USB Key port of the system to be updated and power the system on to boot to the USB Key, by pressing first F11 when on the screen and the press 3

From:

<https://wiki.inf.unibz.it/> - **Engineering-Tech Wiki**

Permanent link:

<https://wiki.inf.unibz.it/doku.php?id=public:bios-upgrade-dl380-g6>

Last update: **2019/06/24 09:51**

